

# Mounting instruction: **SkamoEnclosure Glue**

---



**1** Cut a small hole in the corner of the SkamoEnclosure Glue bag.



**2** Press the SkamoEnclosure Glue bag to remove the air from the bag.



**3** The SkamoEnclosure can now be applied.

- A** Remove dust from the surface of the SkamoEnclosure Board.
- B** Use SkamoEnclosure Primer at the surfaces of the SkamoEnclosure Boards where the SkamoEnclosure Glue will be applied.
- C** Add SkamoEnclosure Glue on top of the SkamoEnclosure Board in a even layer.
- D** Push the SkamoEnclosure Boards in place. Remember SkamoEnclosure Glue binds quickly.
- E** There is no curing time when the SkamoEnclosure Boards are glued, and you can insert the stove immediately.
- F** Remove the excess SkamoEnclosure Glue liquid with a wet cloth. Remove the hardened SkamoEnclosure Glue with a putty knife.